



MOBILE BROADBAND / GLOBALACCESS



VERIZON WIRELESS FIVESPOT™

GlobalReady™ 3G Mobile Hotspot

USER Guide

Contents

Welcome.....	3
The Fivespot Package.....	3
Wireless Communications.....	4
Important Notice	4
Safety hazards	4
Limitation of liability	5
Copyright.....	5
Fivespot Hardware: Overview.....	6
Additional features include	7
About your Fivespot Global Ready 3G Mobile Hotspot.....	7
Care of Your Fivespot.....	8
Ways to Access	8
Getting Started.....	10
Fivespot System Requirements	10
Inserting and charging the battery	10
Installing the SIM Card*	11
Connection options.....	12
Setting up the Fivespot for the First Time.....	13
Connecting to the Internet.....	15
Fivespot Wi-Fi Setting	18
Welcome Page	18
Home Page	19
Basic Setup.....	20
WAN Settings.....	20
Hotspot	22
Wi-Fi Settings.....	23
Firewall	25
Advanced.....	28
Fivespot Specification	30
Troubleshooting	32
Wi-Fi Mode	32
Health and safety information	33
Mobile operation	33
Limiting exposure to radio frequency (RF) fields.....	33
FCC Regulations:	33
Limited Warranty and Liability	34
Glossary.....	35
Trademarks and Service Marks	37

Welcome

Congratulations on purchasing the Verizon Wireless Fivespot™ Global Ready™ 3G Mobile Hotspot for Mobile Broadband and GlobalAccess service!

Before installing the Fivespot™, VZAccess® Manager Software and Drivers, please read this User Manual which describes the features of the device hardware.

The Fivespot is a global data device that operates on the reliable Verizon Wireless Mobile Broadband and GlobalAccess networks* in America, Europe or Asia. 3G Mobile Hotspot is enabling you to connect multiple devices at high speeds to the Internet, your corporate Intranet, Wi-Fi-enabled devices and email virtually anywhere!

Fivespot Technology Bands: CDMA 1X/EVDO Rev0/A 800/1900 MHz; UMTS/HSDPA/HSUPA 900/1900/2100 MHz; GSM/GPRS/EDGE 850/900/1800/1900.

*The service is not available everywhere. Visit www.verizonwireless.com/vzglobal for a complete list of available countries. Information subject to change.

The Fivespot Package

The Verizon Wireless Fivespot package includes:

- Fivespot Global Ready 3G Mobile Hotspot
- Standard Lithium-Ion Battery
- Two-Part USB/Wall Charger
- Global Travel Chargers
- Global Support Kit
- Product Safety & Warranty Brochure
- Quick Reference Guide

Wireless Communications

Important Notice

Due to the transmitting and receiving properties during wireless communications, the data can occasionally be lost or delayed. This can be due to the variation in radio signal strength that results from changes in the characteristics of the radio transmission path. Although the data loss is rare, the environment where you operate the device may adversely affect communications.

Variations in radio signal strength are referred to as fading. Fading is caused by several different factors including signal reflection, signal ionosphere, and signal interference from other radio channels.

Safety hazards

Do not operate device in an environment that may be susceptible to radio interference resulting in danger specifically;
Areas where prohibited by the law

Follow any special rules and regulations and obey all signs and notices. Always turn off the host device and remove the device from the USB port when instructed to do so, or when you suspect that it may cause interference or danger.

Where explosive atmospheres may be present

Do not operate your device in any area where a potentially explosive atmosphere may exist. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Be aware and comply with all signs and instructions.

Users are advised not to operate the device while at a refueling point or service station. Users are reminded to observe restrictions on the use of radio equipment in fuel depots (fuel storage and distribution areas), chemical plants or where blasting operations are in progress.

Areas with a potentially explosive atmosphere are often but not always clearly marked. Potential locations can include gas stations, below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine.

Near Medical and life support equipment

Do not operate your device in any area where medical equipment, life support equipment, or near any equipment that may be susceptible to any form of radio interference. In such areas, the host

communications device must be turned off. The device may transmit signals that could interfere with this equipment.

On an aircraft, either on the ground or airborne

In addition to FAA requirements, many airline regulations state that you must suspend wireless operations before boarding an airplane. Please ensure that the host device is turned off and your device is removed from the USB port prior to boarding aircraft in order to comply with these regulations. The device can transmit signals that could interfere with various onboard systems and controls.

While operating a vehicle

The driver or operator of any vehicle should not operate a wireless data device while in control of a vehicle. Doing so will detract from the driver or operator's control and operation of that vehicle.

In some countries, operating such communications devices while in control of a vehicle is an offense.

Limitation of liability

The information contained in this document is subject to change without notice and should not be construed as a commitment by Verizon wireless Inc.

Copyright

©2010 by Verizon wireless, Inc.

All rights reserved.

Fivespot Hardware: Overview

Thank you for choosing Verizon Wireless Fivespot™ Global Ready™ 3G Mobile Hotspot by ZTE with Mobile Broadband, Global Access and 3G Mobile Hotspot!

With Fivespot Global ready 3G Mobile Hotspot, you can:

- **Connect to High Speed Wireless Data(Mobile Broadband)**
- **GlobalAccess**—GlobalAccess, an extension of Mobile Broadband service, is a high-speed global remote access service available in more than 200 countries, more than 105 with 3G speed, providing a notebook connection to the Internet, corporate intranet and email abroad.

** For more information, a complete list of coverage areas and network providers, visit verizonwireless.com/vzglobal.*

- **3G Mobile Hotspot**

With the Mobile Hotspot, connect via Wi-Fi and access Mobile Broadband to browse the Internet, access email, run businesses applications and more from a computer or most Wi-Fi compatible devices.

- **Manage Wireless Network Activity- VZAccess Manager and Fivespot Settings**

Includes VZAccess Manager software for automatic installation without a CD and easy navigation. The web-based Fivespot Settings is for device status and activation via USB and WI-Fi.

VZAccess Manager: A powerful application tool designed to make piloting your remote office a breeze. VZAccess Manager allows you to manage, monitor, and customize your wireless network activity through an easy-to-use interface.

NOTE:

VZAccess Manager is required for activation and firmware/PRL updates

Fivespot Settings: Allows you to manage, monitor, and customize your Wi-Fi and Mobile Broadband connection through an easy-to-use interface when the device is in Wi-Fi mode (i.e. without the use of the USB cable).

- **Choose between Two connection Modes - USB Cable or Wi-Fi**

Note: The Fivespot needs to be manually powered off then powered on in order to switch between USB and Wi-Fi connection modes. When the Fivespot is powered on after connecting with the computer, it will be in USB mode. When the Fivespot is powered on without connecting to the computer, it will be in Wi-Fi mode.

The Fivespot package includes a battery for both connection modes.


USB Cable is made to supports Windows 7, Vista, XP, 2000; Mac OS x 10.4 or higher.

**See system requirements for a complete list of operation system support.*

Additional features include

- Advanced embedded antenna design for mobile Broadband and Wi-Fi
- VPN capability
- Auto installation and connectivity options
- 2-Way Short Messaging Service (SMS) (VZAccess Manager only)
- GPS/LBS support

About your Fivespot Global Ready 3G Mobile Hotspot







1. Power Key

Press and hold the **Power key** for three seconds to switch the device on, or press and hold the **Power key** for 10 seconds to switch the device off.

NOTE:

*Continuously press the **Power Key** 10 times within 15 seconds to set Wi-Fi related settings to their factory default values, then the device will restart automatically. And each pressing must hold about 1/3 second, otherwise, the pressing will be invalid.*

2. Indicator

Indicator	Icon	Status	Description
Battery		Red solid	Battery is low
		Green blinking	Charging
		Green solid	Battery is charged
Signal strength		Red solid	Signal is weak
		Green solid	Signal is good
Wi-Fi		Green solid	Wi-Fi is active
		LED off:	Wi-Fi is off
Network		LED off	No service
		Green solid	Device is in domestic network with 3G coverage
		Green blinking	Device is in global roaming with 3G coverage
		Red solid	Device is in domestic network with 2G coverage
		Red blinking	Device is in global roaming with 2G coverage

NOTE:

The battery indication LED will be turned off once the battery is fully charged when powered off.

3 Charger/USB port

The device must work with the battery even though it is connected with a charger or PC USB port.

Care of Your Fivespot

As with any electronic device, Fivespot must be handled with care to ensure reliable operation. Verizon Wireless recommends the following handling guidelines:

- Do not apply adhesive labels to Fivespot; they may cause the device to potentially overheat and they may alter the performance of the antenna.
- Using USB data cable carefully connect Fivespot with your computer.
- Protect the Fivespot from liquids, dust, and excessive heat.
- Store the Fivespot in a safe place, when not in use.

Ways to Access

• **Mobile Broadband**—Need to leave the office but don't want to leave your broadband behind? With Verizon Wireless Mobile Broadband, you can work outside the office at broadband speeds. With access to America's most reliable broadband network, you can download complex files and view email attachments at typical speeds of 600 to 1400 Kbps (download) and 500 to 800 Kbps (upload).*

**Speed claim based on our network tests with 5 MB FTP data files without compression. Verizon Wireless is rapidly adding Rev. A capability to your Mobile Broadband service area. Your Mobile Broadband Rev. A-enabled device will indicate coverage when you are in a Mobile Broadband Rev. A service area. When outside the Rev. A service area, your wireless device will revert to Mobile Broadband Rev. 0 (typical download speeds will be 400–700 Kbps and upload speeds will be 60–80 Kbps) or National Access coverage areas, where available. Actual throughput speed and coverage may vary. Speed claims not applicable when roaming.*

• **GlobalAccess**—GlobalAccess, an extension of Mobile Broadband service, is a high-speed global remote access service available in more than 200 countries, more than 105 with 3G speed, providing a notebook connection to the Internet, corporate intranet and email abroad.

**SIM Card required. For more information, a complete list of coverage areas and network providers, visit verizonwireless.com/vzglobal.*

• **3G Mobile Hotspot**—By creating their own Wi-Fi hotspot from their mobile device, users can connect most Wi-Fi-compatible devices to the Internet to: browse web sites, download and view email attachments, run business applications from their computer and more - with the reliability and coverage of Verizon Wireless Mobile Broadband.

NOTE:

When multiple users are connected to the Fivespot, all their data usage will be aggregated and applied to the Mobile Broadband customer's monthly allowance.

• **Verizon Wi-Fi**—Mobile Broadband customers on America's Largest and Most Reliable 3G Network have Internet access at thousands of Verizon Wi-Fi hotspots across the U.S., Canada and Mexico—without using a single megabyte of Mobile Broadband data allowance.

** Verizon Wi-Fi locations include many airports, hotels, restaurants, cafes, bookstores and more.*

** Verizon Wi-Fi gives you a fast connection to the Internet. That means more surfing, more downloading, more email, more social networking—more of everything you use the web for. The best part? It's included with your Mobile Broadband Plan, so there's no additional charge.*

Getting Started

This section provides information and instructions for setting up the Fivespot 3G Global Hotspot for the first time. Before you begin using your device, you must first install VZAccess Manager on your computer. The comprehensive Quick Reference Guide that was included in the box when you purchased your device and the VZAccess Manager Software User Guide details the installation and configuration of your Fivespot with VZAccess Manager.

Important:

Installation must be performed within the Mobile Broadband and/or NationalAccess coverage area.

Important:

Before installing your new software, delete or uninstall any previously existing device or dialer software from your computing system.


Fivespot System Requirements

To install and use Fivespot, your host computer must meet below requirements:


Operating System * IN USB MODEM MODE with USB Cable ONLY	Windows XP (SP3 or higher), Windows Vista (32bit/ 64bit SP1 or higher), Windows 7 NOTE: For details please go to www.vzam.net . - OR - MAC OS X 10.4 or higher
Software	Internet browser software (i.e. Internet Explorer 7, Firefox 3.0 or higher.)
FIVESPOT Software	Mobile Broadband/USB Cable Mode: VZAccess Manager included on the device, no CD required. Wi-Fi Mode: FIVESPOT Settings.
CPU	500 MHz or higher
Interface	One Type-A USB port or 802.11b/g
Memory (RAM)	128 MB
Hard Disk Space	100 MB

Inserting and charging the battery


1. Open the battery compartment, located on the bottom of the device.




2. Insert the battery by lining up the gold contact points on the battery with the gold contact points in the battery compartment.



3. Once the battery is secure, place the battery cover back on the device until it locks into place.



4. Connect the Mini USB end of the AC wall charger to the Mini USB port on the device.



5. Plug the other end of the AC wall charger into the appropriate electrical outlet. Charge at least 5 hours to ensure a full initial charge.

NOTE:

When device is powered on, the battery icon will be solid green notifying the user the battery is fully charged.

WARNING!


Please use only an approved charging accessory to charge your device. Improper handling of the charging port, as well as the use of an incompatible charger, may cause damage to your device and void the warranty.

6. You are now ready to install VZAccess Manager and the drivers. In order to install VZAccess Manager and activate the device, you must use the USB cable (included).

Installing the SIM Card*

Your wireless device comes with an installed SIM Card which, along with a Global plan on your account, enables you to access the internet while traveling outside the U.S. in supported destinations. Should your SIM Card be lost or damaged, please follow these instructions for the installation of your new SIM:

1. Remove SIM Card from the outer card, being careful not to touch the gold contacts.
2. Remove the battery cover from your wireless device. Remove the battery. Hold the card with the Verizon Wireless/Vodafone logo facing you and the gold contact points properly aligned with the SIM Card slot.
3. Insert SIM Card into the slot. The SIM Card may remain in the wireless device permanently once installed (No need to remove).



: Should your SIM Card be lost or damaged please call 1-800-922-0204 to speak with a Customer Service Representative. From outside the U.S. call + 1-908-559-4899 for 24/7 Global Support.

*Your SIM (Subscriber Identity Module) Card is a small rectangular plastic card that stores your phone number and important information about your wireless service.

CAUTION: Do not bend or scratch your SIM Card. Avoid exposing your SIM Card to static electricity, water or dirt.


IMPORTANT: Prior to using GlobalAccess service outside of the U.S., you must:

1. Ensure VZAccess Manager is properly installed on your computer.
2. Ensure a GlobalAccess service plan is activated on your Fivespot.

Connection options

There are two connection options for this device:

- **USB Mode:** Connect the device to your notebook via the included USB cable, then power on your device.



- **Wi-Fi mode:** Power on directly without connecting to notebook. See figure below.



NOTE:

- ◆ *Connect up to five Wi-Fi-enabled devices at once.*
- ◆ *Plug the device directly into a wall outlet or laptop USB port to extend usage time.*

Setting up the Fivespot for the First Time

VZAccess Manager must be installed prior to activation of your device. The first time you use the device, VZAccess Manager must be installed.

VZAccess Manager installation

Getting started with your new wireless device is simple. All you have to do is connect your device to a USB port on your notebook computer using the USB cable included with your device. VZAccess Manager Installer auto-launches and the drivers install automatically once installation is complete. And with the new VZAccess Manager software automatically included with your installation, you'll find that your wireless device is just as easy to use as it is to install.

In most operating systems, VZAccess Manager will launch automatically on your screen once the software is properly installed. (If VZAccess Manager does not open automatically, you can launch it from your Start menu. Refer to software User Guide for complete details.)


Install VZAccess Manager and drivers with the USB cable before installation

IMPORTANT: Installation must be performed via the USB cable prior to activation.

IMPORTANT: Before installing your new software, uninstall any previous version of VZAccess Manager and drivers using the proper Add/Remove Programs steps per your operating system.

Windows

1. Turn on your computer and close all open applications. Make sure your Fivespot is off.
2. Insert the USB cable into the Mini USB port on your device and the other end into the USB port of your computer.



3. To turn your Fivespot on, press and hold the Power button until the signal icon is lit.

VZAccess Manager Installer launches and the device drivers automatically install (this may take a few moments). If VZAccess

Manager does not automatically install, go to **Start >My Computer** and click to open the CD-ROM drive with the Verizon Wireless icon. Double click on **setup.exe** and wait a few moments for the software and drivers to automatically install.

4. Launch VZAccess Manager. The first time you launch VZAccess Manager, the Setup Wizard appears. Follow the on-screen instructions to configure the device. When prompted select **Auto Detect** or **USB Modem** as device type.

5. Select **Verizon Wireless --VZAccess** from the available networks and select **Connect WWAN**. Follow the onscreen prompts


6. If your device was not activated prior to installation of VZAccess Manager, the software will connect to the **Verizon Wireless activation website**. Follow the on-screen instructions to complete the activation.

7. Setup is now complete.

Macintosh

1. Turn on your computer and close all applications. Make sure your Fivespot is off.

2. Insert the USB cable into the Mini USB port on your device and the other end into the USB port of your computer.



3. To turn your Fivespot on, press and hold the Power button until the signal icon is lit. The VZAccess Manager CD icon appears. Click to open and select **VZAccess Manager** to launch the installer. Follow the on-screen instructions to install the software and drivers. After the installation is complete, your Mac will re-start.

4. Launch VZAccess Manager. The first time you launch VZAccess Manager the VZAccess Manager Setup Wizard appears. Following the on-screen instructions to configure the device. When prompted select **USB Modem** as device type.

5. Select **Verizon Wireless --VZAccess** from the available networks and select **Connect WWAN**. Follow the onscreen prompts.

6. If your device was not activated prior to installation of VZAccess Manager, the software will connect to the **Verizon Wireless activation website**. Follow the on-screen instructions to complete the activation.

7. Setup is now complete.

Connecting to the Internet


With your new wireless device and your computer, a wireless Internet connection can always be at your fingertips. Refer to the User Guides on your device to see how easy it is to get connected. The **Fivespot** may be used with or without the USB cable. There are two methods to connect the device to your computer: USB cable or Wi-Fi.

NOTE:

The Fivespot needs to be manually powered off then powered on in order to switch between USB and Wi-Fi connection modes. When the Fivespot is powered on after connecting with the computer, it will be in USB mode. When the Fivespot is powered on without connecting to the computer, it will be in Wi-Fi mode.

Connecting your device with the USB cable

When you connect using the USB cable and then power ON the Fivespot, the following should occur:

- The  turns on (green).
- If you are in 3G coverage, the 3G icon will turn green.
- Launch VZAccess Manager (if not open already) to connect to Mobile Broadband.

Unplugging your device when connected with the USB cable

1. End your Internet session by selecting **Disconnect** from VZAccess Manager.
2. Exit VZAccess Manager.
3. Simply pull the USB cable from your computer and press and hold the **POWER** button to power off your Fivespot.

Connecting your device via Wi-Fi (no USB Cable)


NOTE:

It is recommended the battery be fully charged in order to use the Fivespot in Wi-Fi mode for the first time, or connect the Fivespot to an AC outlet using the AC wall charger provided.

Ensure the power is off and that the USB cable is NOT connected to the computer. The following should occur after you press and hold the **Power** button:

- Your device is powered on and the Signal icon lights up.
- Once your device is powered and has been activated, it automatically connects to the Internet, provided that Mobile Broadband

service is available.

- The  on the device lights solid green to indicate the device is in service and ready to connect.

How to connect your Wi-Fi enabled device to the Fivespot

1. Use your normal Wi-Fi application on your computer to establish a connection to your device.
2. Look for the network (SSID) named “**Verizon AC30 XXXX.**” printed on the back of your Fivespot. The final 4 characters are unique to your device.
3. Click **Connect** and enter the default password printed on the back of your Fivespot and on the device connect instruction card. The password should be the same.

To configure the Fivespot using the Web user interface, go to **http://192.168.0.1** (username and password are both “**admin**”). For details on how to configure the Fivespot with the Web user interface, see the Fivespot Product User Manual on your device.

NOTE:

When multiple users are connected to the Fivespot, all their data usage will be aggregated and applied to the Mobile Broadband customer’s monthly allowance.

NOTE:

*When no user connected to device, the device will enter **sleep mode** in 10 minutes, all LEDs will be turned off. In sleep mode, when click power button, the device will be awoken.*

Verizon Wi-Fi

Mobile Broadband customers on America’s Largest and Most Reliable 3G Network have Internet access at thousands of Verizon Wi-Fi hotspots across the U.S., Canada and Mexico—without using a single megabyte of Mobile Broadband data allowance.

- Verizon Wi-Fi locations include many airports, hotels, restaurants, cafes, bookstores and more.
- Verizon Wi-Fi gives you a fast connection to the Internet. That means more surfing, more downloading, more email, more social networking—more of everything you use the web for. The best part? It’s included with your Mobile Broadband Plan, so there’s no additional charge.

How It Works

- Open VZAccess Manager.
- Connect the Fivespot to your computer with the USB cable.
- Power on your PC-integrated Wi-Fi adapter.
- In VZAccess Manager, select Verizon Wi-Fi Access under Available Network, select Connect Wi-Fi.
- Launch your web browser, email application or other Internet application.

Visit verizonwireless.com/wi-fi for more details and hotspot locations. You can also search for nearby Wi-Fi locations within VZAccess Manager. Customers with Prepaid Mobile Broadband Plans are not eligible for Verizon Wi-Fi access. Verizon Wi-Fi not available on notebooks running MacR OS. Verizon Wi-Fi hotspots are not owned or operated by Verizon Wireless. Verizon Wireless is not able to estimate upload or download speeds at these locations. Customers are responsible for providing security measures for their computers and data. Many Wi-Fi hotspots are not secure. Customers should connect to the Mobile Broadband network when more security is needed.

Check approximate data usage

You can check your approximate unbilled monthly data usage for your Fivespot through the following options:

- * With the Fivespot connected to the computer via USB cable, in VZAccess Manager, click the “Usage” button.
- * Log on to My Verizon or My Business Account.

NOTE:

When multiple users are connected to the Fivespot, all their data usage will be aggregated and applied to the Mobile Broadband customer’s monthly allowance.

Outside of the U.S. and Canada

Using the Fivespot in USB mode:

1. Ensure VZAccess Manager and activation are complete per “The Basics” section prior to leaving the U.S.
2. Ensure the SIM Card is inserted into the Fivespot.
3. Launch VZAccess Manager, if not already running.
4. A message appears to confirm your wireless device. Click **Yes**. VZAccess Manager now searches for a network (may take a few minutes).
5. Verify that you are in a suitable coverage area. Click **Options** tab, select **Test WWAN device**.
6. Select VZGlobal link in the Wireless Networks window. Double click on this or click **Connect**. The word **Connected** appears at the bottom left of the VZAccess Manager window when a connection is established. If not within coverage, a **No Service** message appears. Please ensure you are in a suitable coverage area. For other issues refer to the troubleshooting section of the VZAccess Manager User Guide.

Using the Fivespot in Wi-Fi mode:

Follow the same instructions as the **Connecting your device via Wi-Fi (no USB cable)** section.

Fivespot Wi-Fi Setting

Welcome Page

To connect to the Wi-Fi Settings in the Fivespot, follow this procedure:

1. Establish a Wi-Fi connection to the Fivespot.

-Use your normal WI-Fi manager on your computer to establish a Wi-Fi connection from your computer to the Fivesot.

- The Wi-Fi settings must match those in use on the Fivespot. If using the default settings, refer to the Quick Start Guide for the default values. If you have previously changed the default profile on the Fivespot, or are using a different profile, use the values previously set on the Fivespot.

2. Open your Web Browser

3. In the “**Address**” or “**Location**” bar, enter the address of the Fivespot:

- http://192.168.0.1

4. The Welcome Page appears.



Use the case-sensitive default User name “admin” and default Password “admin”, then Click Login to log in the Setting.

NOTE:

*If you check Save after you give user name and password, the device will save them, next time when you want to log in the device with the same user name and password, what you need to do is click **Login**.*

Home Page

Once you login, the **Welcome** page changes to the **Home** page

Home

WAN Information

Network Provider	Verizon
Network Type	EVDO
Global Access	Home
PPP Status	Disconnected
IP Address	0.0.0.0
Primary DNS	0.0.0.0
Secondary DNS	0.0.0.0

WLAN Information

SSID	Verizon AC30 E8EE
Channel	Auto
Security Level	WPA-PSK
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
Default Gateway	192.168.0.1
DHCP Server	Enable

Copyright (c) 1998-2010 ZTE Corporation. All rights reserved.

- **WAN Information:** Status of WAN information.
- **WLAN information:** Status of Wi-Fi information.
- **System Information:** System status and tips.

Signal strength	: Shows network signal intensity, 5 stages from none to strong .
Internet Status	: Connect internet.
	: Disconnect internet.
SIM card status	: SIM card is not detected.
	: SIM card is detected.

NOTE:

The parameter "Global Access" have several values:

1. **HOME:** Registered on the network of Verizon Wireless.
2. **EXTENDED NETWORK:** Registered on the network of other operators.
3. **INTERNATIONAL:** Roaming outside the USA.
4. **ROAMING:** Roaming.

Basic Setup

Quick Setup

Select **Basic Setup**→**Quick Setup** to access

Basic Setup-->Quick Setup	
•Quick Setup •Password	
SSID	
Name(SSID)	Verizon AC30 0000
SSID Broadcast	Enabled
Encryption Mode	
Encryption Mode	WPA-TKIP
Pre-shared Key	•••••••
Next	

- SSID is used to uniquely identify your WLAN. If you enable **SSID Broadcast**, the gateway will broadcast the SSID, and any Wi-Fi enabled device nearby can detect it.
- Encryption will keep your Fivespot away from unauthorized monitor and access, select one encryption mode from the list, and then set key for it.

Click **Next** to show you new configuration. Then click **Apply** to active your setup.

Password

Select **Basic Setup**→**Password** to access:

Basic Setup-->Password	
•Quick Setup •Password	
Set Current User Password	
Current Password	<input type="password"/>
New Password	<input type="password"/>
Verify Password	<input type="password"/>
Apply Cancel	

You can change password for logging. Click **Apply** to confirm your configurations, or click **Cancel** to cancel your configurations.

WAN Settings

Wireless Info

Select **WAN Settings**→**Wireless Info** to access:

WAN Settings-->Wireless Info

• Wireless Info • Network Select • WAN Connection Mode

WAN Wireless Information

Network Provider	Verizon Wireless
Network Type	1xRTT
Roam	International
RSSI	-110 dBm
HDR_RSSI	-dBm
Ec/Io	-13 dB

Refresh

Click **Refresh** to update the wireless information.

NOTE:

The parameter “Global Access” have several values:

1. **HOME:** Registered on the network of Verizon Wireless.
2. **EXTENDED NETWORK:** Registered on the network of other operators.
3. **INTERNATIONAL:** Roaming outside the USA.
4. **ROAMING:** Roaming.

Network Select

Select **WAN Settings**→**Network Select** to access:

WAN Settings-->Network Select

• Wireless Info • Network Select • WAN Connection Mode

Network Selection Mode

<input checked="" type="radio"/>	Global
<input type="radio"/>	GSM
<input type="radio"/>	CDMA

Apply

- **Global:** Device will automatically register to valid wireless network.
- **GSM:** Device will register to GSM network only.
- **CDMA:** Device will register to CDMA network only.

WAN Connection Mode

Select **WAN Settings**→**WAN Connection Mode** to access:

WAN Settings-->WAN Connection Mode

• Wireless Info • Network Select • WAN Connection Mode

WAN Connection Mode

<input checked="" type="radio"/>	Auto Connect (Domestic Only)
<input type="radio"/>	Auto Connect (GlobalAccess Mode)
<input type="radio"/>	Manual Connect <input type="text" value="Connect Internet"/>
WAN Connection Status	Disconnected

Apply

There are three connection modes:

1. **Auto Connect (Domestic Only):** When registered on CDMA/EVDO network of the United States, the

device will automatically connect to WAN when it is powered on.

2. **Auto Connect (GlobalAccess Mode):** The device will automatically connect to WAN when it is powered on no matter on which network it is registered.

3. **Manual Connect:** Connect/Disconnect to Internet manually.

Click **Apply** to confirm your configuration

Hotspot

LAN

Select **Hotspot**→**LAN** to access:

Hotspot-->LAN	
•LAN •DHCP Clients	
LAN Interface Setup	
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
MAC Address	00:03:7F:35:81:17
DHCP Server	Enable
DHCP IP Pool	192.168.0.100 - 192.168.0.254
DHCP Lease Time	24 hour(s)

Apply Cancel

- **IP Address:** IP address for LAN interface.
- **Subnet Mask:** Subnet mask for the IP address.
- **MAC Address:** MAC address for the LAN interface.
- **DHCP Server:** Enable/Disable DHCP server function.
- **DHCP IP Pool:** Allocate start and end IP address for IP pool.
- **DHCP Lease Time:** Define how long the leased IP address will be expired, and will relocate new IP address.

DHCP Clients

Select **Hotspot**→**DHCP Clients** to access:

Hotspot-->DHCP Clients		
•LAN •DHCP Clients		
DHCP Clients		
Host Name	MAC Address	IP Address
-	00:fd:07:98:9a:11	192.168.0.254

Note: This page is for reference only.


Refresh

Click **Refresh** to update DHCP Clients.

Wi-Fi Settings


Connected Devices

Select **Wi-Fi Settings**→**Connected Devices** to access:



Basic

Select **Wi-Fi Settings**→**Basic** to access:



- **Network Mode:** If all of the wireless devices connect with this device in the same transmission mode, performance will be improved by choosing the appropriate wireless mode.
- **Network Name(SSID):** Service Set Identifier(SSID). Enter a string less than 32 characters as the name for your wireless local area network(WLAN).
- **Broadcast Network Name(SSID):** Disable or Enable(Default) this function. If **Enable** is selected, the device broadcasts the SSID, and other devices can search and connect to it. When you select **Disable**, other devices can not search out the SSID. If you want someone to connect, you need tell them the SSID, and let them to setup manually.
- **AP Isolation:** When **Enable** is selected, each of your wireless clients will not be able to communicate with each other.
- **Country Code:** Choose the right country code.
- **Frequency(Channel):** Choose the appropriate channel to optimize the performance and coverage of your wireless network.
- **Maximum connected Wi-Fi devices:** Choose the maximum number of the stations which connect the AP simultaneously.

Click **Apply** to confirm your configuration, or click **Cancel** to cancel your configuration.

Security

Select **Wi-Fi Settings**→**Security** to access:

Wi-Fi Settings-->Security

•Connected Devices •Basic •Security

Wireless Lan Security

Authentication Type: WPA-PSK

WPA

WPA Algorithms: TKIP AES AUTO

Pass Phrase:

Apply Cancel

Unless one of these encryption modes is selected, wireless transmissions to and from your wireless network can be easily intercepted and interpreted by unauthorized users.

The security modes are described below:

- **OPEN:** You can authenticate successfully with a SSID, whether it is valid or empty.
- **SHARED:** The WLAN clients who have the same WEP key with wireless gateway can pass the authentication and access the wireless network.
- **WPA-PSK:** WPA Pre-Shared Key, Enter the Pre-Shared key as a plain text (ASCII) pass-phrase of at least 8 characters.
- **WPA2-PSK:** It is the securer version of WPA with implementation of the 802.11i standard.
- **WPA Algorithm:** TKIP, AES or AUTO.
- **Pass phrase:** You can input a pass phrase encryption key (8~64 bytes).

If the Authentication type is **OPEN**, the bottom part of the configuration page will appear:

Wi-Fi Settings-->Security

•Connected Devices •Basic •Security

Wireless Lan Security

Authentication Type: OPEN

Encrypt Type: WEP

WEP

Default Key: Key 1

WEP Keys	WEP Key 1 :	<input type="text"/>	ASCII
	WEP Key 2 :	<input type="text"/>	ASCII
	WEP Key 3 :	<input type="text"/>	ASCII
	WEP Key 4 :	<input type="text"/>	ASCII

Apply Cancel

- **Encrypt Type:** Set the encrypt type.
- **WEP Keys:** At most four keys can be set in the blank. Choose the primary key index. The primary key is the only key in use at a given time. Whatever keys you enter for an access point, you must also enter the same keys for the client adapter in the same order. In other words, WEP key 1 on the AP must match WEP key 1 on the client adapter, WEP key 2 on the AP must match WEP key 2 on the client adapter, etc. A WEP is either 10 or 26 hexadecimal digits (0~9,a~f and A~F)based on whether you select 64 bits or 128 bits in the Encryption Strength drop-down list

If the Authentication type is **SHARED**, the bottom part of the configuration page will appear:

Wi-Fi Settings-->Security

•Connected Devices • Basic •Security

Wireless Lan Security

Authentication Type: SHARED

WEP

Default Key: Key 1

WEP Keys	WEP Key 1:	<input type="text"/>	ASCII
	WEP Key 2:	<input type="text"/>	ASCII
	WEP Key 3:	<input type="text"/>	ASCII
	WEP Key 4:	<input type="text"/>	ASCII

Apply Cancel

Firewall

MAC/IP/Port Filtering

Select **Firewall**→**MAC/IP/Port Filtering** to access:

Firewall-->MAC/IP/Port Filtering

• MAC/IP/Port Filtering •Port Forwarding •System Security

Basic Settings

MAC/IP/Port Filtering: Disable

Apply

If you select **Enable**, the filter settings will appear:

Firewall-->MAC/IP/Port Filtering

• **MAC/IP/Port Filtering** • Port Forwarding • System Security

Basic Settings

MAC/IP/Port Filtering: **Enable**

Default Policy -- The packet that doesn't match with any rules would be: **Accepted**

MAC/IP/Port Filter Settings (The maximum rule count is 10)

MAC address: (XX:XX:XX:XX:XX:XX, eg: 00:1E:90:FF:FF:FF)

Dest IP Address: (XXX.XXX.XXX.XXX, eg: 192.168.5.101)

Source IP Address:

Applications: **None**

Protocol: **None**

Dest. Port Range: - (1~65535)

Src Port Range: - (1~65535)

Action: **Drop**

Comment:

Current MAC/IP/Port filtering rules in system:

No. 1 - 10	MAC Address	Dest IP Address	Source IP Address	Protocol	Dest Port Range	Source Port Range	Action	Comment
1								
2								
3								
4								
5								
6								
7								
8								
9								
10								

- **Default Policy:** Set how to handle the packet if none of the rules matches.
- **MAC address:** Set the MAC address that will be filtered.
- **Dest IP Address:** Set the destination IP address that will be filtered.
- **Source IP Address:** Set the source IP address that will be filtered.
- **Applications:** Set which application will be used for filtering.
- **Protocol:** Set which protocol will be used for filtering.
- **Dest. Port Range:** Set the destination port numbers that will be filtered
- **Src Port Range:** Set the source port numbers that will be filtered.
- **Action:** Set how to handle the packet if it matches with the rule.
- **Comment:** type comment for the filter settings.

NOTE:

Filtering rules are matched one by one, if met this provision, it will not continue to match the rules listed below.

Click **Apply** to confirm your configuration. Click **Delete** to delete the rule which you selected. Click **Reset** to

clear what you select or input.

To add a new rule:

- a) Select **Enable** and click **Apply** in the **Basic Settings** area.
- b) Input the detail information in the **Mac/Ip/Port Filtering** area.
- c) Click **Apply** in the **Mac/Ip/Port Filtering** area.

Port Forwarding

Select **Firewall**→**Port Forwarding** to access:

The screenshot shows the 'Firewall-->Port Forwarding' configuration page. At the top, there are three tabs: 'MAC/IP/Port Filtering', 'Port Forwarding', and 'System Security'. Below the tabs, the title is 'Virtual Server Settings (The maximum rule count is 10)'. There is a dropdown menu for 'Virtual Server Settings' currently set to 'Disable'. An 'Apply' button is located at the bottom right.

If you select **Enable**, the Virtual Server Settings will appear:

The screenshot shows the 'Firewall-->Port Forwarding' configuration page with 'Virtual Server Settings' set to 'Enable'. The 'Virtual Server Settings (The maximum rule count is 10)' section is expanded to show the following fields:

- Virtual Server Settings:** Enable
- IP Address : Port:** [] : [] (XXX.XXX.XXX.XXX, eg: 192.168.0.100 : 80)
- Applications:** None
- Dest Port Range:** [] - [] (1~65535)
- Protocol:** TCP+UDP
- Comment:** []

An 'Apply' button is at the bottom right. Below this section is a table titled 'Current Virtual Servers in system:' with 10 rows and 5 columns: No. 1-10, IP Address : Port, Dest Port Range, Protocol, and Comment. The table is currently empty. At the bottom right of the page are 'Delete' and 'Reset' buttons.


- **IP Address: Port:** Set IP address and port number for the virtual server.
- **Applications:** Set which application will be used for the virtual server.
- **Dest Port Range:** Set destination port range for the virtual server.
- **Protocol:** Set protocol for the virtual server.
- **Comment:** Type comment for the virtual server settings.

Select **Enable**, and input the detail information in the **Virtual Server Settings** area, and then click **Apply** to

add a new rule. Click **Delete** to delete the rule which you selected. Click **Reset** to clear what you select or input.

System Security

Select **Firewall**→**System security** to access:




You can enable or disable “log in from WAN” function. Click **Apply** to confirm your configure, or click **Reset** to cancel your configuration.

Advanced

Status


Select **Advanced**→**Status** to access:



System Info	
IMEI	
Wireless access module software version	BD_VERIZONAC30V1.0.0B06
Hardware version	AC30_100101
System Up Time	8 mins, 29 secs

Statistics

Select **Advanced**→**Statistics** to access:




WAN	
WAN Rx data(KB):	0
WAN Tx data(KB):	0
WAN Rx Total data(KB):	0
WAN Tx Total data(KB):	0

Attention: WAN usage (as counted by the device on the Statistics page) is estimated and may not be accurate for billing purposes.

Click **Clean** to clear the result.

Restore&Reboot

Select **Advanced**→**Restore&Reboot** to access:



Click **Restore** to set Wi-Fi related settings to their factory default values, then the device will restart automatically.

Click **Reboot** to restart the device.

Fivespot Specification

Technical Specifications

TABLE 1

Name:	Global Mobile Hotspot
Model:	Verizon Wireless Fivespot™ 3G
Approvals:	FCC , CE , CDG , GCF , CTIA1725 , Wi-Fi
Weight	2.82oz
Dimensions:	3.92in*2.11in*0.55in
Wireless wide-area Network	CDMA2000® 1xEV-DO, UMTS (HSDPA and HSUPA), and GSM/GPRS/EDGE
Chip Set	Qualcomm MSM7625™
Interface Type:	Mini USB Port

TABLE 2

Technology:	CDMA2000 1xRTT/CDMA2000 1xEV-DO, Rev. A/UMTS HSUPA and HSDPA and GSM/GPRS/EDGE
Band Designation:	CDMA2000 1xEV-DO Rev. A at 800/1900 MHz. WCDMA 3GPP Release 5 and HSUPA Release 6 at 900/1900 / 2100 MHz.
Transmit Band:	CDMA band classes: BC0: 824 to 849 MHz, BC1: 1850 to 1910 MHz. UMTS operating bands: Band I: 1920 to 1980 MHz, Band II: 1850 to 1910 MHz, Band VIII 880 To 915MHz. GSM operating bands: GSM 850: 824 to 849 MHz, GSM 900: 890 to 915 MHz. DCS 1800: 1710 to 1785 MHz, PCS 1900: 1850 to 1910 MHz.
Receive Band:	CDMA band classes: BC0: 869 to 894 MHz, BC1: 1930 to 1990 MHz UMTS operating bands: Band I: 2110 to 2170 MHz, Band II: 1930 to 1990 MHz, Band VIII 925 to 960MHz. GSM operating bands: GSM 850: 869 to 894 MHz, GSM 900: 935 to 960 MHz.

GPS	1500MHz
Wi-Fi Bands	2400MHz-2483.5MHz

TABLE 3

Operating Temperature	32°F to 95°F
Storage Temperature	-4 to 122°F
Relative Humidity	5%~ 95%
Drop	3.937FT drop, no damage – fully operational
Vibration Stability	5HZ-500HZ.0.1 octave/second

NOTE:

- *Do not leave the device or the battery in places where the temperature could exceed 122°F, e.g. on a car dashboard or a windowsill, behind glass in direct sunlight, etc.*
- *Charging is only possible within a temperature range of 32°F to 113°F.*
- *The device can be placed in the closed space (such as: pocket or bag). Because the closed environment is not conductive to heat, when the device works for a long time, it will overheat and automatically shut down or disconnect from network for security prevention. When this situation occurs, please remove the device to the ventilation environment to take the heat, and then continue to use it.*
- *Do not try to use the device while the temperature of the environment is above 95°F.*

Troubleshooting

Wi-Fi Mode

I cannot access the internet at all.

1. Please check your configuration settings.
2. Please wait 1~2 minutes for the device to initialize.
3. Check your service indicator LED's.

I forget the Wi-Fi password that I set before

- Please press the power key continually 10 times within 15 seconds, then AC30 will reboot automatically with the default Wi-Fi password being restored. The default password can be found on the bottom label.

The download or upload speeds are very slow.

- The speed is dependent on signal strength. Check your signal strength and network type.

The RSSI signal indicator is always blinking or does not light.

- This indicates poor reception. Try moving the device to another location near the window.

Health and safety information

Mobile operation

Important safety information regarding radio frequency (RF) radiation exposure. To ensure compliance with RF exposure guidelines the phone must be used with a minimum of 20 cm separation from the body. Failure to observe these instructions could result in your RF exposure exceeding the relevant guideline limits.

Limiting exposure to radio frequency (RF) fields

For individuals concerned about limiting their exposure to RF fields, the World Health Organization (WHO) provides the following advice:

Precautionary measures: Present scientific information does not indicate the need for any special precautions for the use of devices. If individuals are concerned, they might choose to limit their own or their children's RF exposure by limiting the length of calls, or using 'hands-free' devices to keep devices away from the head and body.

Further information on this subject can be obtained from the WHO home page <http://www.who.int/peh-emf> WHO Fact sheet 193: June 2000.

FCC Regulations:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and radiates radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Limited Warranty and Liability

ZTE Corporation warrants for the 12 month period immediately following receipt of the Device by Purchaser that the Device will be free from defects in material and workmanship under normal use. THESE WARRANTIES ARE EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

The exclusive remedy for a claim under this warranty shall be limited to the repair or replacement, at ZTE

Corporation' option, of defective or non-conforming materials, parts or components. The foregoing warranties do not extend to (I) non conformities, defects or errors in the Devices due to accident, abuse, misuse or negligent use of the Devices or use in other than a normal and customary manner, environmental conditions not conforming to ZTE Corporation' specification, of failure to follow prescribed installation, operating and maintenance procedures, (II) defects, errors or nonconformity's in the Device due to modifications, alterations, additions or changes not made in accordance with ZTE Corporation' specifications or authorized by ZTE Corporation, (III) normal wear and tear, (IV) damage caused by force of nature or act of any third person, (V) shipping damage, (VI) service or repair of Device by the purchaser without prior written consent from ZTE Corporation, (VII) devices designated by ZTE Corporation as beta site test samples, experimental, developmental, reproduction, sample, incomplete or out of specification Products, or (VIII) returned products if the original identification marks have been removed or altered.

Glossary

1xRTT

Short for single carrier (1x) Radio Transmission Technology. A high speed wireless technology based on the CDMA platform. 1xRTT has the capability of providing broadband-like speeds of up to 144 Kbps. 1xRTT is also referred to as CDMA2000.

1xEVDO

Part of a family of CDMA2000 1x digital wireless standards. 1xEVDO is a "3G" standard. EVDO stands for "EVolution, Data-Optimized." 1xEVDO is based on a technology initially known as "HDR" (High Data Rate) or "HRPD" (High Rate Packet Data), developed by Qualcomm. The international standard is known as IS-856. 1xEVDO has the capability of providing broadband-like speeds of average speeds of 400-700 kbps.

bps

Bits per second – rate of data flow.

Broadband

High-capacity high-speed, transmission channel with a wider bandwidth than conventional modem lines. Broadband channels can carry video, voice, and data simultaneously.

Computing Device

Personal Computing device (notebook, desktop computer, tablet PC, PDA, etc).

Kbps

Kilobits per second – rate of data flow

LAN

Local Area Network. A data network confined to limited area with moderate to high data rates. Does not use common carrier circuits, although may have gateways or bridges to other public or private networks.

Mbps

Megabits per second

PDA

Personal Digital Assistant. A handheld device used for organization, notes, address books, etc.

Rev A

CDMA EV-DO Rev. A is a leading-edge wireless technology with higher data rates and higher system capacity.

It is a fully backward compatible standard and remains interoperable with deployed EV-DO networks and devices around the world. The increased data rates on Rev. A's physical layer enable richer applications and services.

For more information, visit www.cdg.org.

SMS

Short Messaging Service. Short text messages of generally no more than 140-160 characters sent and received by wireless devices.

USB

Universal Serial Bus. A connection type for computing device peripherals such as a printer, mobile device, etc.

VPN

Virtual Private Network. A way to communicate through a dedicated server securely to a corporate network over the Internet.

WAN / WWAN

Wide Area Network (WAN). A computer network covering a broad geographical area. WANs are used to connect local area networks (LANs) together, so that users and computers in one location can communicate with users and computers in other locations.

WWAN

Wireless Wide Area Network (WWAN). Also called "wireless broadband" or "broadband wireless," wireless WANs (WWANs) use cellular towers to transmit a wireless signal over a range of several miles to a mobile device compared to wireless Wi-Fi LANs (WLANs), which span only a few hundred feet and generally to only stationary devices.

Trademarks and Service Marks

Verizon Wireless is a trademark of Verizon Trademark Services LLC, and the other trademarks, logos, and service marks (collectively the "Trademarks") used in this user manual are the properties of Verizon Wireless or their respective owners. Nothing contained in this user manual should be construed as granting by implication, estoppel, or otherwise, a license or right of use of Verizon Wireless or any other Trademark displayed in this user manual without the written permission of Verizon Wireless or its respective owners.

VZAccess ManagerSM is a service mark of Verizon Wireless.

Microsoft® and Windows® are either registered trademarks or trademarks of Microsoft® Corporation in the United States and/or other countries.

The names of actual companies and products mentioned in this user manual may be the trademarks of their respective owners.

Contents of this help file, Copyright 2007 Verizon Wireless, all rights reserved.