User Manual

(Multi-language LED Digit board)

Type: C16128R
Version: 6.02

1. Summary

1.1 Accessory

C16128R
550mm×105mm×22mm   Weight:1000g
Standard Parts

USB Cord	CD-ROM

Charge Adapter (option parts)

2. Features:

1)   16*128 dot matrix.
2)   Multi- language. It displays 16 Western characters or 8 Asian Characters.
3)   6 Text Message, each of them displays 250 western characters.
4)   2 Images Message (max.384x12 pixels. It's better use black font with white background BMP image.
5)   11 twinkled animations embedded and a brightness font.

6) It's easy to select run sequence of 8 messages and adjust to the brightness (25%, 50%, 75%, 100%)
7) Set up time fuction.
8) Set up time/count
9) The Software uses Under Windows Vinsta/XP/2000/98.

10) Large capability Poly-lion Battery with 2500mAh.Recharging 2 hours when it will work

more than 10 hours.

11) Single mini USB interface for charging   and communicating.

3. The keys and interfaces of LED Digit board

There are 4 buttons on the right of LED Digit Board. Any detail information as below:

亮度调节　Brightness　Adjust

节目选择　Message Selector

USB 口　USB Port

电源开关　ON/OFF

Attention: The RS232 port is easy to broke, please input it carefully or it maybe can't charge and communication.

1.1 Switch On/Off your Digit Board
Firstly, make sure the battery with electricity before usage. Turn on the switch, and the pre-stored message will run automatically. The switch turned off or the battery used out, the badge will turn off automatically.

1.2 How to use your LED Digit Board
It used widely in public house, meeting room, shopping, In front of the Supermarket and

so on.

The following Bracket can be chosen if you want.

4. Operation Software

Edited message can be sent to Digit Board through USB Communication. All contents of CD-ROM as following:

1) Click on the CD-ROM, then some files showing:

,产品光盘\C16128R

  📁 Digibo program
  📁 USB Driver
  📁 节目示例
  📄 Manul of Digibo.doc
  📄 中文使用手册.doc

PL-2303 Driver Installer.exe
Prolific Technology Inc

Firstly, click on USB Driver, then chick on the Logo   .It install automatically by itself.

DigiBo.exe

Secondly, click on Digibo program, then click on Logo   The edition surface will be stared.

LED Digit Board V6.02[untitle.bge]

File   Picture   Speed   Action   Font   Help

MSG1   Speed Action Long Send

		Speed	Action	Long	Send
1		5	SC	0	☑
2		5	SC	0	☑
3		5	SC	0	☑
4		5	SC	0	☑
5		5	SC	0	☑
6		5	SC	0	☑
7	Logo1 Del	5	SC	0	☑
8	Logo2 Del	5	SC	0	☑

Com Port
AUTO ▾

Run Sequence: 12345678

Max Chars : 250 x 6 = 1500

🖼 Image Editor

🟢 Send   0%

Pull down

2) Please click on the right Tri-angle Logo if you want to choose another language or setup character size.


3) From the first to the sixth text message which is edit message. The rest two is LOGO editing.

   Input mesage

1> Text Message: Editing directly from the first one to the sixth.

2> Input animation on the Text message when cursor staying in that place. Then click on the built-in animation, it will be inserted. Notes: on the Text Message, animation displays its code.

3>Speed, Staying Time, Action

4> How to make single letter act. It is the function which is some letter or some paragraph

jump except the normal 5 actions. Insert "Logo before or back the letter or font. Text message only displays code.

5> lock, Timer and Count function：Move the cursor on the Message bar,then click on that action. Time message window will come out:

After one and one inserting year,month, date, it will show the following content.

You also can inputting some Char. after DY,DL or DD, then sending them to the Digibo.

Screen will display that content what you want.

6) Edit Image. It can be input 2 pieces of LOGO Message. Please click on the Image that means to choose. Click on "Del" that means to delete.

1> Logo message usual form is BMP File. It is better use black letter and white background. Dot matrix is within 384. The length is not limited. But the software only can deal within 12 dot matrixes.

2> How to edit Image File. The software enclosed like ImageEditor.exe. Please click on the button of Image Editor. Save edited image to Disk. Then use the function of image to choose.

3> 8 Run sequence. It supplies a function of redefined message sequence. For example, 87654321 or 6327 are both right sequence which is accordance with message sent or chosen.

5.Communication:

1) Connect the Digit Board USB Port to the computer one. Then click on the Editor, sending them after editing finished. The message will be uploaded to Digit Board directly.

2) Choose port. It is usually based on your fact to choose. If using dummy USB port, the software will setup AUTO or setup COM3. If using port communication cable, it usually use AUTO.

6.Special Function

1) Digit Board can display upright way. Click on the icon will be come out. Please refer to the following picture 1.

2)Picture 2

3) Connect it to the computer

Any detail process, please refer to the following picture.

Communicating and charging

7) Charge

    Charging time is about 3 hours if it is use out of electricity.

Turn on the Digit Board, then connected to the computer. At that time, the screen will display charging icon which is showing current electricity capability. After finished, the screen will display full charging icon.

    The last step is separate Digit Board from charger or the computer. Turn off it.

Notice: long time charging has no any effect on the life-span of battery.

====================== Thank you for using it ==========================